

## MBE Vehicle List

Vehicle type	Brand	Model	Version	Engine	Engine Type	Fuel	CV	MY	To	BSI Version	All Keys Lost Option	EZS MCU Type	Key MCU Type	Starter Kit	Evo Kit	Maxi Kit
Car	Mercedes	B	(W246)					2011	2013	Up to FBS3	X	NEC 51/57 only	BGA	FULL	FULL	FULL
Car	Mercedes	B	(W245)					2005	2010	Up to FBS3	X	Motorola	NEC sw 51/57	Calc only	FULL	FULL
Car	Mercedes	CLS	(W218)					2007	2013	Up to FBS3	X	NEC 51/57 only	BGA	FULL	FULL	FULL
Car	Mercedes	E	(C207)					2009	2013	Up to FBS3	X	NEC 51/57 only	BGA	FULL	FULL	FULL
Car	Mercedes	E	(W212)					2008	2013	Up to FBS3	X	NEC 51/57 only	BGA	FULL	FULL	FULL
Car	Mercedes	GL	(W166)					2012	2013	Up to FBS3	X	NEC 51/57 only	BGA	FULL	FULL	FULL
Car	Mercedes	M	(W164)					2009	2013	Up to FBS3		NEC 51/57 only	BGA	FULL	FULL	FULL
Car	Mercedes	M	(W166)					2009	2013	Up to FBS3	X	NEC 51/57 only	BGA	FULL	FULL	FULL
Car	Mercedes	ML	(W166)					2009	2013	Up to FBS3	X	NEC 51/57 only	BGA	FULL	FULL	FULL
Car	Mercedes	SLC	(W172)					2011	2013	Up to FBS3		NEC 51/57 only	BGA	FULL	FULL	FULL
Car	Mercedes	Viano	(W639)					2009	2013	Up to FBS3		NEC 51/57 only	BGA	FULL	FULL	FULL
Car	Mercedes	CL	(W216)					2005	2013	Up to FBS3		NEC 51/57 only	BGA	FULL	FULL	FULL
Car	Mercedes	SLS	(W197)					2009	2013	Up to FBS3	X	NEC 51/57 only	BGA	FULL	FULL	FULL
Car	Mercedes	Vito	(W639)					2009	2013	Up to FBS3		NEC 51/57 only	BGA	FULL	FULL	FULL
Car	Mercedes	S	(W221)					2005	2013	Up to FBS3		NEC 51/57 only	BGA	FULL	FULL	FULL
Car	Mercedes	C	(W204)					2007	2013	Up to FBS3	X	NEC 51/57 only	BGA	FULL	FULL	FULL
Car	Mercedes	A	(W169)					2004	2012	ALL		NEC 51/57	BGA	FULL	FULL	FULL

Vehicle type	Brand	Model	Version	Engine	Engine Type	Fuel	CV	MY	To	BSI Version	All Keys Lost Option	EZS MCU Type	Key MCU Type	Starter Kit	Evo Kit	Maxi Kit
												only				
Car	Mercedes	GL	(W164)					2009	2012	ALL		NEC 51/57 only	BGA	FULL	FULL	FULL
Car	Mercedes	E	(W211)					2002	2010	ALL		NEC 51/57 only	BGA	FULL	FULL	FULL
Car	Mercedes	CLK	(W209)					2003	2009	ALL		NEC 51/57 only	BGA	FULL	FULL	FULL
Car	Mercedes	CLS	(W219)					2004	2009	ALL	X	Motorola	NEC sw 51/57	Calc only	FULL	FULL
Car	Mercedes	G	(W463)					2002	2009	ALL	X	Motorola	NEC sw 51/57	Calc only	FULL	FULL
Car	Mercedes	R	(W251)					2005	2009	ALL	X	Motorola	NEC sw 51/57	Calc only	FULL	FULL
Car	Mercedes	SL	(R230)					2001	2009	ALL	X	Motorola	NEC sw 51/57	Calc only	FULL	FULL
Car	Mercedes	SLK	(R171)					2004	2009	ALL	X	Motorola	NEC sw 51/57	Calc only	FULL	FULL
Car	Mercedes	Sprinter	(W906)					2005	2009	ALL	X	Motorola	NEC sw 51/57	Calc only	FULL	FULL
Car	Mercedes	M	(W164)					2005	2009	ALL	X	Motorola	NEC sw 51/57	Calc only	FULL	FULL
Car	Mercedes	GL	(W164)					2006	2009	ALL	X	Motorola	NEC sw 51/57	Calc only	FULL	FULL
Car	Mercedes	Viano	(W639)					2004	2009	ALL	X	Motorola	NEC sw 51/57	Calc only	FULL	FULL
Car	Mercedes	Vito	(W639)					2004	2009	ALL	X	Motorola	NEC sw 51/57	Calc only	FULL	FULL
Car	Mercedes	C	(W203)					2003	2007	ALL	X	Motorola	BGA	Calc only	FULL	FULL
Car	Mercedes	CL	(W215)					2001	2006	ALL	X	Motorola	Motorola	Calc only	FULL	FULL
Car	Mercedes	S	(W220)					2001	2005	ALL	X	Motorola	Motorola	Calc only	FULL	FULL
Car	Mercedes	CLK	(W208)					2001	2002	ALL	X	Motorola	Motorola	Calc only	FULL	FULL

Vehicle type	Brand	Model	Version	Engine	Engine Type	Fuel	CV	MY	To	BSI Version	All Keys Lost Option	EZS MCU Type	Key MCU Type	Starter Kit	Evo Kit	Maxi Kit
Car	Mercedes	E	(W210)					2001	2002	ALL	X	Motorola	Motorola	Calc only	FULL	FULL